
3 ways to issue card for time attendance

1. Connect Card issuer ASM100 to Issue card


Connect Card issuer ASM100



• Add User manually, it says Card Reader connected! No need driver.



 Move cursor to Card NO. Box, left click, after long beeps, the reader start to receive card.(only after you left click the card no box, the reader starts to receive and issue card no ,Reader indicator turn green)




Notice: after adding user successfully, please don't forget to upload user to device.


2. Fill Card No. Manually

 When you punch the unregistered card in device, you could get the card NO, for example: 872322593, Decimal.

But for smartpss, in default, display the card in Hexadecimal, not Decimal





• Switch the card NO display in Decimal as below. Then fill in the NO and save



3. Download the device info to get the User info (include card No)

Select device ,and right click->download User Info->Extract to User





Device also supports to add user in batch. It can add card user very quick.
6 Features->input start use ID, just need to punch card one by one



