## 1. Check the Firmware Version

Firmware: DH\_IPC-HX8X4X-Kronos\_Eng\_P\_Stream3\_V2.622.0000000.1.R.180117.zip




## 2. People Counting Setting

--Smart Plan->Enable People Counting




## --Ground Calibration

Daw a rectangle and save. Camera will automatically calculate the height and angle right now. you can also do the adjustment.



You can't Enable A&B function together.

- A. People Counting (Line Crossing)
- Enable people counting
- Draw the rule
- Enable OSD
- You can enable the alarm due to the counting numbers.



- B. People Counting(Area)
- Enable In Area No.
- Draw the rule
- Enable OSD and Inside Number

