

NOBEL V3.000.0000001.R.210623

Release Notes





Legal Information

Copyright

© 2021 ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD. All rights reserved.

This document cannot be copied, transferred, distributed, or saved in any form without the prior written permission of Zhejiang Dahua Vision Technology Co., LTD (hereinafter referred to as "Dahua").

The products described in this document may contain the software that belongs to Dahua or the third party. Without the prior written approval of the corresponding party, any person cannot (including but not limited to) copy, distribute, amend, abstract, reverse compile, decode, reverse engineer, rent, transfer, sublicense the software.

Trademarks



All other company names and trademarks mentioned herein are the properties of their respective owners.

Disclaimer

- These release notes are for reference only, and the actual product shall prevail.
- Succeeding products and release notes are subject to change without notice.
- If there is any uncertainty or controversy, please refer to our final explanation.



Table of Contents

Legal Information	
Release Notes	
1.1 Overview	
New Features	
1.3 Fixed Bugs	2
1.4 Compatibility	2
1.4.1 Program	2
1.4.2 Browser	2
1.4.3 Third Party Access	
1.5 Software Environment	3
1.6 Pending Issues	3
1.7 Update Guide	



Release Notes

1.1 Overview

Item	Description
Product model	Nobel platform series
Version	V3.000.0000000.1.R.210623
Software	DH_IPC-HX8XXX-Nobel_MultiLang_PN_V3.000.0000000.1.R.210623.zip
package	DH_IPC-HX8XXX-Nobel_MultiLang_NP_V3.000.0000000.1.R.210623.zip
information	DH_IPC-HX8XXX-NODEI_MUMLANG_NP_V3.000.0000000.1.K.210625.2ip
OS requirement	None
Release date	June 30, 2021

New Features

Features	Description	
Face & body detection and PPE	PPE detection.	
detection	General mode: General face & body detection.	
Face recognition and advanced customer counter	 General mode: General face recognition, which supports non-living filtering and target box overlay. It also supports configuring event report and email linkage according to database. Counting mode: Except general face databases, there are two default function databases AllPeople database and ExcludePeople database, therefore, 3 types of databases are supported. It supports 7 databases consisting of 50,000 images. AllPeople database and ExcludePeople database cannot be deleted. 	
Target direction statistics	On the global configuration interface of video metadata you can enable Tripwire Counting , and select direction according to the actual scene. • With Tripwire Counting enabled, the snapshot mode for human, motor and non-motor vehicle detection is switched to Tripwire . • With Tripwire Counting disabled, video metadata configuration will restore to general settings.	
Dahua file system	Supports Dahua file system (DHFS).	
Privacy masking	Supports mosaic block and color lump. You can draw up to 8 color lumps and 4 mosaic blocks. Mosaic only supports drawing rectangles, and color lump	

1



	supports drawing polygons.	
	Switched to European algorithm.	
Updated ANPR 1.0 algorithm	Updated motor vehicle attributes: Supports detections	
	of license plate, vehicle color, vehicle type, vehicle logo,	
	seatbelt, smoking, and calling.	
	Updated video tampering algorithm on the video	
Updated video tampering algorithm	detection interface.	
	Added covered area and duration parameters.	

1.3 Fixed Bugs

Fixed Bugs	Description		
Compatibility of earlier and later versions	If the version earlier than V3.000.0000000.1.R.210517 is		
	updated to V3.000.0000000.1.R.210517 or later, Al		
	configuration of ANPR cannot be sent. You must restore		
	to the default settings before the configuration can be		
	send normally.		
Auto-delete fault for AllPeople database	After setting the auto-delete time for AllPeople		
	database, it does not automatically delete information		
	according to the set time. For example, set auto-delete		
	time as 7 days, but it deletes information every day.		

1.4 Compatibility

1.4.1 Program

- For IPC-HX71242X:
 2.6.01.05.22457:DH_IPC-HX8XXX-Nobel_MultiLang_NP_V2.800.0000000.5.R.200525.zip
 2.6.01.05.21691:DH_IPC-HX8XXX-Nobel_MultiLang_PN_V2.800.0000000.5.R.200525.zip
- For IPC-HF74(8)42X, IPC-HFW74(8)42X, IPC-HDBW74(8)42X:
 2.6.01.05.22457:DH_IPC-HX8XXX-Nobel_MultiLang_NP_V2.800.00000005.R.200525.zip
 2.6.01.05.21691:DH_IPC-HX8XXX-Nobel_MultiLang_PN_V2.800.00000005.R.200525.zip
- For IPC-HF74(8)(12)42X , IPC-HFW74(8) (12)42X , IPC-HDBW74(8) (12)42X:
 2.6.01.05.35911: DH_IPC-HX8XXX-Nobel_MultiLang_NP_V3.000.0000000.1.R.210517.zip
 2.6.01.05.35909: DH_IPC-HX8XXX-Nobel_MultiLang_PN_V3.000.0000000.1.R.210517.zip

1.4.2 Browser

- WIN7+ Chrome 86
- WIN7+ Firefix88
- WIN7+ IE9/IE10/IE11



1.4.3 Third Party Access

• CGI testing tool version: V2.91.0.8

• ONVIF testing tool version: V20.06

• ONVIF: Supports ProfileG, T, S

MILESTONE 2020R3

1.5 Software Environment

Platform	Model	Version	
	Net SDK	General_NetSDK_Eng_Win64_IS_V3.052.0000002.0.R.200923.7z	
		General_NetSDK_Eng_Win32_IS_V3.052.0000002.0.R.200923.7z	
SDK		General_PlaySDK_Eng_Windows64_IS_V3.044.0000000.1.R.21031	
JUK	Dlayedk	2.zip	
	Playsdk	General_PlaySDK_Eng_Windows32_IS_V3.044.0000000.1.R.21031	
		2.zip	
NVR	DH_NVR5XXX-IL_MultiLang_V4.002.0000000.0.R.2		
NVR NVR5X-I/L		(informal Release)	
NVR	NVR5X-4KS2	Customer_NVR5XXX-4KS2_MultiLang_DH_V4.000.0000000.0.R.20	
		200114.zip	
EVS	EVS71	DH_EVS71XX_Eng_V4.001.0000002.0.R.200909.BIN	
LVJ			
IVSS	IVSS7XX	DH_IVSS7XX_Eng_V2.002.0000000.0.R.201106.zip	
	IOS: Download the latest version on App Store		
APP DMSS		Android: Download the latest version on Google Play.	
	Dlavor	General_SmartPlayer-Win32_Eng_IS_V4.001.0000001.0.R.200916.z	
Tools	Player	ip	
10015	ConfigTool	General_ConfigTool_ChnEng_V5.000.0000001.6.R.20210126.zip	
DCC	DSS Pro	General DSS-Pro Win64 IS V8.000.0000001.0.R.20201215.exe	
D22 – –			
NVD	DH-NVDxx05D	General_VideoNexus-NVD0405DH-2I-4K_Eng_V3.200.0000000.11.	
	H-4K	R.190321.BIN	

1.6 Pending Issues

No.	Issue Description	Possible Result	How to Fix
1	Abnormal face recognition	When using IE9 browser, with	Use another browser such as
	report exported through	Counting Mode enabled, the face	Google Chrome
	IE9.	recognition report exported is	
		abnormal.	
2	Abnormal display of web	After switching language on IE9,	Clear browser cache
	interface on IE9.	occasionally some interfaces	

3



	cannot be loaded.	

1.7 Update Guide

- Do not disconnect the network, reboot and turn off the camera during update.
- When upgrading with the false file, you need to reboot the device, otherwise some functions might be disabled.

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

Address: No.1199, Bin'an Road, Binjiang District, Hangzhou, P.R. China

Postcode: 310053 Tel: +86-571-87688883

Fax: +86-571-87688815

Email: overseas@dahuatech.com Website: www.dahuasecurity.com